

Install

Install Procedures

- CDROM contains all Tools and Class Material
- Explore CD in your computers
- Copy Class material onto your C drive
- Install MPLAB 8.0
 - Accept when queried for HI-TECH Compiler install
- Install PICKIT2

Set-up PICKIT2 Hardware Programmer/Debugger

- Must download firmware into PICKIT2 before it can be accessed by MPLAB
- Double Click PICKIT icon
- Select Tools and “Download PICKIT2 OS”
- Browse and Navigate through C:\Program Files\Microchip\Pickit2 and select OS shown
- Plug-in USB cable from computer to PICKIT@
- The PICKIT will then download the selected OS and the PICKIT 2 should now be functional

